
## **ROTHCO OUTERWEAR SIZE CHART**

## **Special Ops Tactical Soft Shell Jacket**

Size	Chest Width (IN)	Sleeve Length (IN)	Back Length (IN)
xs	21.25	24.80	27.17
S	22.44	25.60	27.95
м	23.62	26.38	28.74
L	24.81	27.17	29.53
XL	25.99	27.95	30.32
2XL	27.17	28.67	31.10
3XL	28.35	29.53	31.89
4XL	29.53	30.32	32.38
5XL	30.71	31.10	32.68
6XL	31.89	31.89	33.07
7XL	33.07	32.68	33.46
8XL	34.25	33.46	33.86



How to Measure: Measure from armpit to armpit to find the chest width. For the sleeve length, measure from the shoulder point to the end of the cuff. The back length can be found by measuring from the high point shoulder to the bottom edge of the jacket.

Use the chart to find your measurement.